

# DIGITAL TV SETUP



**Connect the television correctly  
and turn it on.**



**Go to the setup menu of your  
television and select something like  
'digital tuning'**



**Follow the instructions of the menu  
and use the following settings:**

frequency: **47400, 474000 or 474**    network ID: **4444**  
provider: **UPC or Ziggo**    symbolfreq.: **6900**  
modulation: **64QAM**

Do you need help? At [www.ziggo.nl/klantenservice/televisie-radio/digitale-tv/kabel-tv-installeren](http://www.ziggo.nl/klantenservice/televisie-radio/digitale-tv/kabel-tv-installeren) you will find setup instructions for all television brands (in Dutch). When you need to enter an address, you can use 'postcode' **3065 AA** and 'huisnummer' **1**.